

DATA SHEET

DRIVING STUD FOR FORGED ROD

Driving stud is to transfer the vibrations from the tup to earth rod. It should be placed in the feather key of the rod and should be imbedded with the hammer.

Cat. no.	Diameter of rod mm	Material
C1080375	14.2	steel
C1080395	16.0	
C1080385	17.2	



The manufacturer reserves the right to change the product design without prior notice.